



How to fill a Greenkey Pressure Sprayer



Before use, make sure that the hose fitting and pressure release valve are tight to prevent air escaping during use. Next, firmly screw spray lance to the hose unit. Check that the trigger lock is in the off position.

1. Push the pump handle down
2. Unscrew the pump mechanism by turning the handle anticlockwise so it pushes against the lugs. Continue turning anticlockwise to unscrew and then withdraw from the tank.
3. Fill liquid to the desired volume. Do not exceed stated maximum fill.
4. Before you insert the pump unit, dry inside the filler funnel. Insert pump and tighten.

FOR FURTHER ADVICE PLEASE CALL 01594 560200

FINISHING. Check that the sprayer is not pressurised by pulling the pressure release valve and holding until all the air has been released. **DO NOT RELEASE THE PRESSURE BY UNSCREWING THE PUMP UNIT.** After you have ensured that the sprayer is holding no pressure, unscrew the pump unit and empty any liquid left in the bottle. Refill the bottle with approx. 2l clean tap water, pressurise the sprayer and allow it to empty.

STORAGE. Make sure the sprayer is not pressurised and contains no liquid. Do not store in direct sunlight. Store out of reach of children

WARNING.

This sprayer is for use with pesticides, herbicides and fertilizers. Only use water based garden chemicals

DO NOT use solvents or petroleum based products. For protection against harmful chemicals, safety goggles, mask and protective clothing should be worn when operating. Do not spray on windy days or near children or animals.

www.greenkey-garden.co.uk